

# HOW TO SWITCH THE METAL CLIP IN MASTER'S IWB HOLSTER TO THE OTHER SIDE



**What you'll need:**

TWO screwdrivers, one of them must be flat-head screwdrivers.

Use of protective gear (gloves & goggles) is recommended.



**Step 1:**

Insert a flathead screwdriver under the clip to pry up the end of the leather cutout on the bottom part of the clip where the metal lip catches on to the leather. This keeps the clip open and makes it easier to start pulling the clip out.



**Step 2:**

Insert the second screwdriver through the clip, this helps to get a good grip on the clip to start pulling it out. Grab both ends of the second screwdriver and start pulling the clip out.



**Step 3:**  
Pull the clip out completely.  
FLIP the holster to the other side  
→



**Step 4:**  
Insert the flat-head screwdriver through the clip holes on the holster from the bottom hole through the top hole in order to use as a guide for the clip.



**Step 5:**  
Slide the clip onto the exposed screwdriver head such that it keeps the clip opened up. This makes it easier to slide the clip into the top opening.  
The bottom lip of the clip needs to slide under the leather, start pushing the clip in place starting from the top cutout in leather.

**Step 6:**

Push and slide the clip towards the screwdriver. Once the bottom lip of the clip starts to slide under the top leather cutout, you can pull the screwdriver out.

Keep pushing the clip to slide it into place.



**Step 7:**

Push and slide the clip all the way down into place. The bottom lip of the clip must be seated in the bottom cutout and it must catch on to the leather cutout to stop it from coming out.